



UVS4

Desktop ultraviolet
disinfection lamp

High-power disinfection for small areas

15_{min}
0.55m²

30_{min}
1m²

60_{min}
2m²



Features



Safety by design

A motion sensor will detect any movement within 5 meters and immediately deactivate the lamp and sound an alarm.



Safe start

2 minutes delayed start with audible alarms. Once the disinfection time is set, the lamp will be turned on after a delay of 2 minutes allowing people and pets to leave the room.



Childlock function

Double protection



Fall protection -Auto Power Off

When lamp detects a movement of more than 45°, it will automatically power off, thus preventing heat damage to surrounding objects, should the lamp fall over.



No Ozone

Safe and harmless – Leave no residue
Note: Only when used in accordance with manufacturer instructions



Remote control

Through the wall



High quality lamp



Quartz glass tube

Allows full transmission of ultraviolet light

Application areas

Car, closet, shoe cabinet, suitcase, cabinet and bathroom



Product information

Product: GOLDENSEA UV Desktop Disinfection Lamp

Model: UVS4

Light Source Wattage: 4W

Light Source Lifespan: Max. 6000h

Voltage: 100V-240V/50-60Hz

Current: Max. 30mA

Control: Touch keys + remote control

Material: Anti-UV ABS and quartz glass

Function: UV disinfection

Wavelength: 253.7nm

Cable Length: 1.8m

Compliance: CE, ETL, FCC

Application: car, closet, shoe cabinet, suitcase, cabinet and bathroom



Warning

Ultraviolet light can cause damage to eyes and skin.

All personnel, animals and plants must leave/ be moved from the site during use.

Precautions

1. Ultraviolet disinfection lamp products emitting UV-C at 253.7nm must only be used in an environment with no living things present (humans, animals, plants). Ultraviolet light may cause skin redness, itching, peeling, and eye conjunctive damage caused by electro-optical ophthalmitis.

Never look directly at the lamp without suitable eye protection when it is powered on and emitting light. It is essential that all people and pets leave the room before the lamp is turned on and only re-enter the room after the lamp has been turned off/ has finished its disinfection cycle.

2. Ultraviolet has a degrading effect on many materials including plastics, paper and cloth. Exposure to irradiation over long periods of time may cause the surface of the

irradiated objects to change color and or become more brittle. Never use ultraviolet sterilization lamp products emitting direct irradiation on expensive clothing, ornaments, calligraphy, painting and other valuables.

3. The surface of the lamp tube should be kept clean when using the UV disinfection lamp. It is recommended to clean the lamp tube regularly when not in use (usually every 2 weeks). When cleaning, please use a soft clean cotton cloth with a small amount of alcohol to wipe the lamp tube surface, remove the dust and oil.

4. A side effect of disinfection can be an abnormal smell, similar to that of the sun drying wet bedding, we recommend that spaces are well ventilated for 10-15 minutes following disinfection.

5. UV lamps should be properly protected after disinfection and placed out of reach of children, in a safe place.

6. Impact and strong vibration may cause the lamp tube to break. Should the lamp tube break, immediately turn off the power supply and dispose of the lamp, wearing protective gloves and according to your local toxic and harmful garbage rules. Should a lamp break, immediately open the windows for 10-15 minutes of ventilation.

7. Never disinfect areas with inflammable or explosive items as you may otherwise cause burning or explosion.

8. If the lamp tube needs to be replaced, replace only with the original brand of lamp tube and complete the operation according to the procedures in the user manual.